

# Refrigerant R410A Duct Type SPLIT TYPE AIR CONDITIONER INSTALLATION INSTRUCTION SHEET

(PART NO. 9372633052-04)

Indoor unit is an appliance not accessible to the general public.

For authorized service personnel only.

<b>WARNING</b>	This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of the user.
<b>CAUTION</b>	This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.

## This air conditioner uses new refrigerant HFC (R410A).

The basic installation work procedures are the same as conventional refrigerant models. However, pay careful attention to the following points:

- Since the working pressure is 1.6 times higher than that of conventional refrigerant models, some of the piping and installation and service tools are special. (See the table below.) Especially, when replacing a conventional refrigerant model with a new refrigerant R410A model, always replace the conventional piping and flare nuts with the R410A piping and flare nuts.
- Models that use refrigerant R410A have a different charging port thread diameter to prevent erroneous charging with conventional refrigerant and for safety. Therefore, check beforehand. [The charging port thread diameter for R410A is 1/2 UNF 20 threads per inch.]
- Be more careful that foreign matter (oil, water, etc.) does not enter the piping than with refrigerant models. Also, when storing the piping, securely seal the openings by pinching, taping, etc.
- When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge from the liquid phase side whose composition is stable.
- When moving, if the compressor stops during pump down, close the valve immediately.

### Special tools for R410A

Tool name	Contents of change
Gauge manifold	Pressure is high and cannot be measured with a conventional gauge. To prevent erroneous mixing of other refrigerants, the diameter of each port has been changed. It is recommended the gauge with seals -0.1 to 5.3 MPa (-76 cmHg to 53 kgf/cm <sup>2</sup> ) for high pressure. -0.1 to 3.8 MPa (-76 cmHg to 38 kgf/cm <sup>2</sup> ) for low pressure.
Charge hose	To increase pressure resistance, the hose material and hose size were changed.
Vacuum pump	A conventional vacuum pump can be used by installing a vacuum pump adapter.
Gas leakage detector	Special gas leakage detector for HFC refrigerant R410A.

### Copper pipes

It is necessary to use seamless copper pipes and it is desirable that the amount of residual oil is less than 40 mg/10m. Do not use copper pipes having a collapsed, deformed or discolored portion (especially on the interior surface). Otherwise, the expansion valve or capillary tube may become blocked with contaminants. As an air conditioner using R410A incurs pressure higher than when using conventional refrigerant, it is necessary to choose adequate materials. Thicknesses of copper pipes used with R410A are as shown in the table. Never use copper pipes thinner than that in the table even when it is available on the market.

### Thicknesses of Annealed Copper Pipes (R410A)

Pipe outside diameter	Thickness
6.35 mm (1/4 in.)	0.80 mm
9.52 mm (3/8 in.)	0.80 mm
12.70 mm (1/2 in.)	0.80 mm
15.88 mm (5/8 in.)	1.00 mm
19.05 mm (3/4 in.)	1.20 mm

## CONNECTING PIPE REQUIREMENT

**CAUTION**  
The maximum lengths of this product are shown in the following table. If the units are further apart than this, correct operation can not be guaranteed.

Pipe outside diameter	Pipe length		Maximum height (between indoor and outdoor)
	Liquid	Gas	
9.52 mm (3/8 in.)	19.05 mm (3/4 in.)	50 m	5 m
			30 m

• Use pipe with water-resistant heat insulation.

**CAUTION**  
Install heat insulation around both the gas and liquid pipes. Failure to do so may cause water leaks. Use heat insulation with heat resistance above 120 °C. (Reverse cycle model only) In addition, if the humidity level at the installation location of the refrigerant piping is expected to exceed 70%, install heat insulation around the refrigerant piping. If the expected humidity level is 70-80%, use heat insulation that is 15 mm or thicker and if the expected humidity exceeds 80%, use heat insulation that is 20 mm or thicker. If heat insulation is used that is not as thick as specified, condensation may form on the surface of the insulation. In addition, use heat insulation with heat conductivity of 0.045 W/(m·K) or less (at 20 °C).

## ELECTRICAL REQUIREMENT

• Electric wire size and breaker capacity:

Power supply cable (mm <sup>2</sup> )		Connection cable (mm <sup>2</sup> )		Breaker capacity (A)
MAX.	MIN.	MAX.	MIN.	
4.0	2.5	2.5	1.0	20

- Always use H07RN-F or equivalent to the connection cable.
- Install all electrical works in accordance to the standard.
- Install the disconnect device with a contact gap of at least 3 mm in all poles nearby the units. (Both indoor unit and outdoor unit)
- Install the circuit breaker nearby the units.

## SELECTING THE MOUNTING POSITION

Decide the mounting position with the customer as follows:

**WARNING**  
Select installation locations that can properly support the weight of the indoor and outdoor units. Install the units securely so that they do not topple or fall.


- CAUTION**
- Do not install where there is the danger of combustible gas leakage.
  - Do not install the unit near heat source of heat, steam, or flammable gas.
  - If children under 10 years old may approach the unit, take preventive measures so that they cannot reach the unit.

### INDOOR UNIT

- Install the indoor unit on a place having a sufficient strength so that it withstand against the weight of the indoor unit.
- The inlet and outlet ports should not be obstructed; the air should be able to blow all over the room.
- Leave the space required to service the air conditioner.
- Install the unit where the drain pipe can be easily installed.
- Providing as much space as possible between the indoor unit and the ceiling will make work much easier.

### (For maintenance)

- Maintenance work of the control box is possible with the maintenance hole of the measurement shown in the figure.
- If maintenance work is to be done from the bottom side, the maintenance hole needs to be larger than the outside dimension of the indoor unit.
- If maintenance work is to be done from the top, keep the space of the more than 500 mm between the indoor unit and ceiling.



## INSTALLATION PROCEDURE

### 1 INDOOR UNIT INSTALLATION

**WARNING**  
① Install the air conditioner in a location which can withstand a load of at least five times the weight of the main unit and which will not amplify sound or vibration. If the installation location is not strong enough, the indoor unit may fall and cause injuries.  
② If the job is done with the panel frame only, there is a risk that the unit will come loose. Please take care.



**CAUTION**  
For installation, refer to the technical data.

### RECOMMENDED RANGE OF EXTERNAL STATIC PRESSURE


100Pa~250Pa

### 1. INSTALLING THE HANGERS

Hanging bolt installation diagram.




**CAUTION**  
Fasten the unit securely with special nuts A and B.



The side A of the unit with the drain port should be slightly lower than the opposite side B of the unit. The height difference between sides A and B should be from 0 to 20 mm.


### 3. MOUNTING THE DUCT

Follow the procedure in the following figure to install the ducts.



\* Spacing between flange and drain pan.

**CAUTION**  
① If an intake duct is installed, take care not to damage the temperature sensor (the temperature sensor is attached to the intake port flange).  
② Be sure to install the air inlet grille and the air outlet grille for air circulation. The correct temperature cannot be detected. Grills must be installed so that man can't touch unit fan, and can't be removed by only hand operation with tool.




③ Be sure to install the air filter in the air inlet. If the air filter is not installed, the heat exchanger may be clogged and its performance may decrease.


## 2 OUTDOOR UNIT INSTALLATION

### 1. OUTDOOR UNIT PROCESSING

① Outdoor unit to be fastened with bolts at the four places indicated by the arrows without fail.




② Fix securely with bolts on a solid block. (Use 4 sets of commercially available M10 bolt, nut and washer.)



- Since the drain water flows out of the outdoor unit during heating operation, install the drain pipe and connect it to a commercial 16 mm hose. (Reverse cycle model only)
- When installing the drain pipe, plug all the holes other than the drain pipe mounting hole in the bottom of the outdoor unit with putty so there is no water leakage. (Reverse cycle model only)

**CAUTION**  
When the outdoor temperature is 0 °C or less, do not use the accessory drain pipe and drain cap. If the drain pipe and drain cap are used, the drain water in the pipe may freeze in extremely cold weather. (Reverse cycle model only)



**WARNING**

- For the air conditioner to operate satisfactorily, install it as outlined in this installation instruction sheet.
- Connect the indoor unit and outdoor unit with the room air conditioner piping and cables available from our standard parts. This installation instruction sheet describes the correct connections using the installation set available from our standard parts.
- Installation work must be performed in accordance with national wiring standards by authorized personnel only.
- If refrigerant leaks while work is being carried out, ventilate the area. If the refrigerant comes in contact with a flame, it produces a toxic gas.
- Do not turn on the power until all installation work is complete.
- During installation, make sure that the refrigerant pipe is attached firmly before you run the compressor. Do not operate the compressor under the condition of refrigerant piping not attached properly with 2-way or 3-way valve open. This may cause abnormal pressure in the refrigeration cycle that leads to breakage and even injury.
- During the pump-down operation, make sure that the compressor is turned off before you remove the refrigerant piping. Do not remove the connection pipe while the compressor is in operation with 2-way or 3-way valve open. This may cause abnormal pressure in the refrigeration cycle that leads to breakage and even injury.
- When installing and relocating the air conditioner, do not mix gases other than the specified refrigerant (R410A) to enter the refrigerant cycle. If air or other gas enters the refrigerant cycle, the pressure inside the cycle will rise to an abnormally high value and cause breakage, injury, etc.

- Be careful not to scratch the air conditioner when handling it.
- After installation, explain correct operation to the customer, using the operating manual.
- Let the customer keep this installation instruction sheet because it is used when the air conditioner is serviced or moved.

## STANDARD PARTS

The following installation parts are furnished. Use them as required.

### INDOOR UNIT ACCESSORIES

Name and Shape	Q'ty	Application
Special nut A (large flange)	4	For suspending the indoor unit from ceiling
Special nut B (small flange)	4	
Coupler heat insulation (large)	1	For indoor side pipe joint (gas pipe)
Coupler heat insulation (small)	1	For indoor side pipe joint (liquid pipe)

Name and Shape	Q'ty	Application
Binder	1	For fixing the remote controller cable
Remote controller	1	
Tapping screw (flush heads)	2	For installing the remote controller
Remote controller cable	1	For connecting the remote controller

### OUTDOOR UNIT ACCESSORIES

Name and Shape	Q'ty	Application
Drain pipe	1	For outdoor unit drain piping work (May not be supplied, depending on the model.)
Drain cap	2	
Insulation (seal)	1	For filling in a gap at the entrance of connection cables.

## OPTIONAL PARTS

The following options are available.


- Long-life filter : UTD-LP60KA (P/N 9017230004).
- Simple remote controller : UTB-YFB (P/N 9077522006)
- Remote sensor : UTD-RS100 (P/N 9072619004)
- External control set : UTD-ECCSSA (P/N 9077359004)

### OUTDOOR UNIT


**WARNING**  
① Install the unit where it will not be tilted by more than 5°.  
② When installing the outdoor unit where it may be exposed to strong wind, fasten it securely.

- Install the outdoor unit in a location which can withstand the weight of the unit and vibration, and which can install horizontally.
- Provide the indicated space to ensure good airflow.
- If possible, do not install the unit where it will be exposed to direct sunlight. (If necessary, install a blind that does not interfere with the airflow.)
- Do not install the unit near a source of heat, steam, or flammable gas.
- During heating operation, drain water flows from the outdoor unit. Therefore, install the outdoor unit in a place where the drain water flow will not be obstructed. (Reverse cycle model only)
- Do not install the unit where strong wind blows or where it is very dusty.
- Do not install the unit where people pass.
- Install the outdoor unit in a place where it will be free from being dirty or getting wet by rain as much as possible.
- Install the unit where connection to the indoor unit is easy.

- When there are obstacles at the back side.
- When there are obstacles at the back and front sides.



- When there are obstacles at the back, side(s), and top.
- When there are obstacles at the back side with the installation of more than one unit.



\* If the space is larger than that is stated, the condition will be the same as that there are no obstacles.

## 3 CONNECTING THE PIPE

**CAUTION**  
① Do not use mineral oil on flared part. Prevent mineral oil from getting into the system as this would reduce the lifetime of the units.  
② While welding the pipes, be sure to blow dry nitrogen gas through them.  
③ The maximum lengths of this product are shown in the table. If the units are further apart than this, correct operation can not be guaranteed.

### 1. FLARING

- Cut the connection pipe to the necessary length with a pipe cutter.
- Hold the pipe downward so that cuttings will not enter the pipe and remove the burrs.
- Insert the flare nut (always use the flare nut attached to the indoor and outdoor units respectively) onto the pipe and perform the flare processing with a flare tool. Use the special R410A flare tool, or the conventional (for R22) flare tool.



Pipe outside diameter	Dimension A (mm)	
	Flare tool for R410A, clutch type	
6.35 mm (1/4 in.)	9.1	
9.52 mm (3/8 in.)	13.2	
12.70 mm (1/2 in.)	16.6	
15.88 mm (5/8 in.)	19.7	
19.05 mm (3/4 in.)	24.0	

Pipe outside diameter	Dimension B (mm)	
	Dimension B ±0.4 (mm)	
6.35 mm (1/4 in.)	9.1	
9.52 mm (3/8 in.)	13.2	
12.70 mm (1/2 in.)	16.6	
15.88 mm (5/8 in.)	19.7	
19.05 mm (3/4 in.)	24.0	


When using conventional flare tools to flare R410A pipes, the dimension A should be approximately 0.5 mm more than indicated in the table (for flaring with R410A flare tools) to achieve the specified flaring. Use a thickness gauge to measure the dimension A.

Pipe outside diameter	Width across flats of Flare nut
6.35 mm (1/4 in.)	17 mm
9.52 mm (3/8 in.)	22 mm
12.70 mm (1/2 in.)	26 mm
15.88 mm (5/8 in.)	29 mm
19.05 mm (3/4 in.)	36 mm

### 2. BENDING PIPES

The pipes are shaped by your hands. Be careful not to collapse them. Do not bend the pipes in an angle more than 90°. When pipes are repeatedly bent or stretched, the material will harden, making it difficult to bend or stretch them any more. Do not bend or stretch the pipes more than three times.

**CAUTION**  
① To prevent breaking of the pipe, avoid sharp bends. Bend the pipe with a radius of curvature of 150 mm or over.  
② If the pipe is bent repeatedly at the same place, it will break.




### 3. CONNECTION PIPES

Indoor unit

(1) Detach the caps and plugs from the pipes.

**CAUTION**  
① Be sure to apply the pipe against the port on the indoor unit correctly. If the centering is improper, the flare nut cannot be tightened smoothly. If the flare nut is forced to turn, the threads will be damaged.  
② Do not remove the flare nut from the indoor unit pipe until immediately before connecting the connection pipe.

(2) Centering the pipe against port on the indoor unit, turn the flare nut with your hand.




To prevent gas leakage, coat the flare surface with alkylbenzene oil (HAB). Do not use mineral oil.

### 4. INSTALLING THE DRAIN PIPES

Install the drain pipes according to the measurements given in the following figure.

Flange position for connecting the drain pipes




**CAUTION**  
① This product has drain ports in two locations. Follow the procedure in the figure to connect drain pipes to each of them.  
② Be sure to properly insulate the drain pipes.

Use general hard polyvinyl chloride pipe (VP25) and connect it with adhesive (polyvinyl chloride) so that there is no leakage. Do not perform air bleeding.

① Main drain pipe

Provide one trap on the main drain pipe near the indoor unit.



② Safety drain  
There is no need to provide a trap for the safety drain pipe. If the safety drain pipe is connected to the main drain pipe, make the connection below the trap on the main drain pipe.</

### 3 CONNECTING THE PIPE

#### 5. ADDITIONAL CHARGE

Refrigerant suitable for a piping length of 20 m is charged in the outdoor unit at the factory. When the piping is longer than 20 m, additional charging is necessary. For the additional amount, see the table below.

Pipe length	20 m	30 m	g/m
Additional refrigerant (R410A)			
Cooling model	None	300 g	30 g/m
Reverse cycle model	None	400 g	40 g/m

Pipe length	40 m	50 m	g/m
Additional refrigerant (R410A)			
Cooling model	600 g	900 g	30 g/m
Reverse cycle model	800 g	1200 g	40 g/m

#### CAUTION


- When moving and installing the air conditioner, do not mix gas other than the specified refrigerant R410A inside the refrigerant cycle.
- When charging the refrigerant R410A, always use an electronic balance for refrigerant charging (to measure the refrigerant by weight).
- When charging the refrigerant, take into account the slight change in the composition of the gas and liquid phases, and always charge from the liquid phase side whose composition is stable.
- Add refrigerant from the charging valve after the completion of the work.
- The maximum length of piping is 50 m. If the units are further apart than this, correct operation can not be guaranteed.

### 6. GAS LEAKAGE INSPECTION

#### CAUTION

- After connecting the piping, check the all joints for gas leakage with gas leak detector.
- When inspecting gas leakage, always use the vacuum pump for pressure. Do not use nitrogen gas.

### 7. HEAT INSULATION ON THE PIPE JOINTS (INDOOR SIDE ONLY)



#### CAUTION

There should be no gaps between the insulation and the product.

### 4 POWER

#### WARNING

- The rated voltage of this product is 400 V 3 φ 50 Hz.
  - Before turning on, verify that the voltage is within the 342 V to 457 V range.
  - Always use a special branch circuit and install a special receptacle to supply power to the air conditioner. (Install in accordance with standard.)
  - Use a special branch circuit breaker and receptacle matched to the capacity of the air conditioner. (Install in accordance with standard.)
  - Perform wiring work in accordance with standards so that the air conditioner can be operated safely and positively.
- Install a leakage special branch circuit breaker in accordance with the related laws and regulations and electric company standards.

#### CAUTION

- The power source capacity must be the sum of the air conditioner current and the current of other electrical appliances. When the current contracted capacity is insufficient, change the contracted capacity.
- When the voltage is low and the air conditioner is difficult to start, contact the power company the voltage raised.
- This air conditioner must be connected to a power source that has an electrical impedance of 0.16 Ω or less or has a supply current of 100 A or greater. If the power supply does not meet the specifications, contact the power company.


### 5 ELECTRICAL WIRING

#### WARNING

- Before starting work, check that power is not being supplied to the indoor unit and outdoor unit.
- Match the terminal board numbers and connection cable colors with those of the outdoor unit. Erroneous wiring may cause burning of the electric parts.
- Connect the connection cables firmly to the terminal board. Imperfect installation may cause a fire.
- Always fasten the outside covering of the connection cable with the cable clamp. (If the insulator is chafed, electric leakage may occur.)
- Always connect the ground wire.

#### HOW TO CONNECT WIRING TO THE TERMINALS


- A. For solid core wiring (or F-cable)**
- Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 25 mm to expose the solid wire.
  - Using a screwdriver, remove the terminal screw(s) on the terminal board.
  - Using pliers, bend the solid wire to form a loop suitable for the terminal screw.
  - Shape the loop wire properly, place it on the terminal board and tighten securely with the terminal screw using a screwdriver.
- B. For strand wiring**
- Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 10 mm to expose the strand wiring.
  - Using a screwdriver, remove the terminal screw(s) on the terminal board.
  - Using a round terminal fastener or pliers, securely clamp a round terminal to each stripped wire end.
  - Position the round terminal wire, and replace and tighten the terminal screw using a screwdriver.



#### CAUTION

Do not bundle the remote controller cable, or wire the remote controller cable in parallel, with the indoor unit connection wire (to the outdoor unit) and the power supply cable. It may cause erroneous operation.

#### 1. CONNECTION DIAGRAMS




#### 2. CONNECTION CABLE PREPARATION



#### 3. INDOOR UNIT


- CAUTION**
- Use care not to mistake the power supply cable and connection wires when installing.
  - Install so that the wires for the remote controller will not come in contact with other connection wires.



#### C. Indoor unit/remote controller setting (room temperature sensor selection)

The temperature sensor of the indoor unit or the remote controller can be used to detect the room temperature.

- Press the THERMO SENSOR button for 5 seconds or more to unlock the function. The thermo sensor display flashes and then disappears when the function is unlocked.
- Press the THERMO SENSOR button to select the temperature sensor of the indoor unit or the remote controller.





#### CAUTION

- When select the "Remote controller setting", if the detected temperature value between the temperature sensor of the indoor unit and the temperature sensor of the remote controller varies significantly, it is likely to return to the control status of temperature sensor of the indoor unit temporarily.
- As the temperature sensor of remote controller detects the temperature near the wall, when there is a certain difference between the room temperature and the wall temperature, the sensor will not detect the room temperature correctly sometimes. Especially when the outer side of the wall on which the sensor is positioned is exposed to the open air, it is recommended to use the temperature sensor of the indoor unit to detect the room temperature when the indoor and outdoor temperature difference is significant.
- The temperature sensor of the remote controller is not only used when there is a problem in the detection of the temperature sensor of the indoor unit.


#### NOTES

If the function to change the temperature sensor is used as shown in examples A and B (other than example C), be sure to lock the detection location. If the function is locked, the lock display will flash when the THERMO SENSOR button is pressed.




### 2. ROUTING THE REMOTE CONTROLLER WIRES

- Install the remote controller wires to the terminals on the top of the rear case as shown in the following figure.
- Fasten the wires with the binder.



### 3. SETTING THE DIP SWITCHES

When using a battery (memory backup)




Change the DIP switch setting to use batteries. (The DIP switch is not set to use batteries at the factory.) Change DIP switch No. 6 from OFF to ON. If batteries are not used, all of the settings stored in memory will be deleted if there is a power failure.

### 4. SETTING THE ROOM TEMPERATURE DETECTION LOCATION

The detection location of the room temperature can be selected from the following three examples. Choose the detection location that is best for the installation location.

#### A. Indoor unit setting (factory setting)

The room temperature is detected by the indoor unit temperature sensor.



#### B. Remote controller setting

The room temperature is detected by the remote controller temperature sensor.

- Press the THERMO SENSOR button for 5 seconds or more to unlock the function. The thermo sensor display flashes and then disappears when the function is unlocked.
- Press the THERMO SENSOR button. The thermo sensor display appears.
- Press the THERMO SENSOR button again for 5 seconds or more to lock the function. The thermo sensor display flashes and then remains on when the function is locked.
- Make sure that the function is locked.

### 7 TEST RUN

#### CAUTION

Supply power to the crankcase heater for at least 12 hours before the start of operation in winter.

- Stop the air conditioner operation.
- Press the MODE button and the FAN button simultaneously for 2 seconds or more to start the test run.
- Press the START/STOP button to stop the test run.

#### [SELF-DIAGNOSIS]

When the error indication "E.EE" is displayed, follow the following items to perform the self-diagnosis. "E.EE" indicates an error has occurred.

#### 1. REMOTE CONTROLLER DISPLAY

- Stop the air conditioner operation.
- Press the SET TEMP. buttons A/V simultaneously for 5 seconds or more to start the self-diagnosis. Refer to the following tables for the description of each error code.
- Press the SET TEMP. buttons A/V simultaneously for 5 seconds or more to stop the self-diagnosis.

Error code	Error contents
00	Communication error (indoor unit ↔ remote controller)
01	Communication error (indoor unit ↔ outdoor unit)
02	Room temperature sensor open
03	Room temperature sensor short-circuited
04	Indoor heat exchanger temperature sensor open
05	Indoor heat exchanger temperature sensor short-circuited
06	Outdoor heat exchanger temperature sensor open
07	Outdoor heat exchanger temperature sensor short-circuited
08	Power source connection error
09	Float switch operated
0A	Outdoor temperature sensor open
0b	Outdoor temperature sensor short-circuited

Error code	Error contents
0C	Discharge pipe temperature sensor or compressor temperature sensor open
0d	Discharge pipe temperature sensor or compressor temperature sensor short-circuited
0E	Outdoor high pressure error
0F	Discharge pipe temperature or compressor temperature error
11	Model error
12	Indoor fan error
13	Outdoor signal error
14	Outdoor EEPROM error

#### 2. OUTDOOR UNIT LEDS

Heat & Cool model (reverse cycle) only

When a malfunction occurs in the outdoor unit, the LEDs on the circuit board light to indicate the error. Refer to the following table for the description of each error according to the LEDs.

LED1	LED2	Error contents
flash	flash	Model abnormal or EEPROM error
1 flash	Lighting	Power source connection error
2 flash	Lighting	Discharge temp. sensor error
3 flash	Lighting	Heat exchanger temp. sensor error
4 flash	Lighting	Outdoor temp. sensor error
5 flash	Lighting	Communication signal error
6 flash	Lighting	Indoor unit error
7 flash	Lighting	Discharge temp. error
8 flash	Lighting	High pressure error
9 flash	Lighting	Compressor temp. error
10 flash	Lighting	Compressor temp. sensor error
	Dislighting	No error. Protect operation

When the fault is cleared, the LED lamp goes off. However, for discharge pipe temperature abnormal and high pressure abnormal, the LED lamp lights continuously for 24 hours, as long as the power is not turned off.


### 8 SPECIAL INSTALLATION METHODS

#### CAUTION


- When setting the rotary switch and DIP switches, do not touch any other parts on the circuit board directly with your bare hands.
- Be sure to turn off the main power.

#### 1. GROUP CONTROL SYSTEM

A number of indoor units can be operated at the same time using a single remote controller.




- Rotary switch setting (indoor unit) Set the unit number of each indoor unit using the rotary switch on the indoor unit circuit board. The rotary switch is normally set to 0.
- DIP switch setting (remote controller) Change DIP switch No. 3 on the remote controller from OFF to ON.



#### 2. DUAL REMOTE CONTROLLERS (OPTIONAL)

Two separate remote controllers can be used to operate the indoor units.



- Wiring method (indoor unit to remote controller)


### 6 REMOTE CONTROLLER SETTING

#### CAUTION

- When detecting the room temperature using the remote controller, please set up the remote controller according to the following conditions. If the remote controller is not well set, the correct room temperature will not be detected, and thus the abnormal conditions like "not cooled" or "not heated" will occur even if the air-conditioner is running normally.
  - A location with an average temperature for the room being airconditioned.
  - Not directly exposed to the outlet air from the air-conditioner.
  - Out of direct sunlight.
  - Away from the influence of other heat sources.
- When installing the remote controller and cable near a source of electromagnetic waves, separate the remote controller from the source of the electromagnetic waves and use shielded cable.
- Do not touch the remote controller PC board and PC board parts directly with your hands.


#### 1. INSTALLING THE REMOTE CONTROLLER

- Open the operation panel on the front of the remote controller, remove the two screws indicated in the following figure, and then remove the front case of the remote controller.



When installing the remote controller, remove the connector from the front case. The wires may break if the connector is not removed and the front case hangs down. When installing the front case, connect the connector to the front case.

- Install the rear case to the wall, etc. with the two tapping screws. Refer to the following information to install the remote controller wires.



Install the remote controller wires so as not to be direct touched with your hand.

#### 2) DIP switch setting (remote controller)

Set the remote controller DIP switch Nos. 1 and 2 according to the following table.

Number of remote controllers	Master unit		Remote controller
	DIP-SW No. 1	DIP-SW No. 2	
1 (Normal)	ON	OFF	
2 (Dual)	OFF	OFF	

Number of remote controllers	Slave unit	
	DIP-SW No. 1	DIP-SW No. 2
1 (Normal)	-	-
2 (Dual)	ON	ON

#### 3. CANCELING AUTO RESTART

The auto restart function can be cancelled.

- DIP switch setting (indoor unit) Change the DIP switch (SW2-3) on the indoor unit circuit board from OFF to ON. The auto restart function will be cancelled.



#### [DIP-SWITCH SETTING]

NO.	SW state		Detail
	OFF	ON	
SW2 DIP-Switch	1	- *	Remote sensor setting
	2	Edge *	Control input setting
	3	Validity *	Auto restart setting

#### Remote controller

NO.	SW state		Detail	
	OFF	ON		
DIP-Switch	1	*	Dual remote controller setting	
	2	*	Group control setting	
	3	One unit *	Multiple unit *	
	4	Heat & Cool model	Cooling only model	Model setting
	5	Invalidity	Validity *	Auto changeover setting
	6	Invalidity *	Validity	Memory backup setting

\*: Factory setting